

Vevor Double Slush Machine

Operation Instructions

Before use of the machine, verify all parts are clean and assembled properly.

Do not use extension cord, plug directly into a secured outlet.

Make sure to use the correct slush mixture.

Incorrect mixture can result in an ice blockage or contents will not freeze to the correct consistency.

Recommended mixture (1 part slush mix to 4 parts water)

Not recommended to use outdoors in direct sunlight.

Proper Slush consistency will take about 1-1.5 hours.

Indoor use of machine

(Freeze setting should not exceed level 3 if indoors)

Before powering machine on, make sure freeze is at level 1

Level 1 – 10-15 Minutes

Level 2 – 20-30 minutes

Level 3 – 20-30 minutes

Once the contents reach proper consistency, keep machine at level 3.

Outdoor use of machine

(Freeze setting can go up to level 4)

Before powering machine on, make sure freeze is at level 1

Level 1 – 10-15 minutes

Level 2 – 15-20 minutes

Level 3 – 20-30 minutes

If mixture consistency is not thick enough after 30 minutes on level 3, move to level 4.